


2. Device-side Configuration

Configuring Studio Express on the device is very simple and straightforward.

- Disable or enable Studio Express
- Show or hide the information of Studio Express on the home-screen

To access these configurations, click on “Settings” button.



“Home-screen Config” and “Studio Express” buttons will take you to the actual configuration.

Settings

- Home-screen Config
- Studio Express
- Auto-Play Setup
- Device Password
- Software Update
- General Settings

Home-screen Config

- ☒ Device Info
- ☒ Connection Info
- ☒ Studio Express

Save Cancel

Studio Express

☐ Disable
☒ Enable

Apply Cancel