

5.2 Organization

If you want to set up your team member as different role, and upload your company logo. You can go to “Organization”. Below is the introduction.



In “Organization”, you can see the information of name, ID, current users, and also can set up user as Administrator, Installer.

For upload company logo, Remote Manager Cloud supports PNG, BMP, JPEG, JPG format.