

6. License management

Remote Manager Cloud is a paid cloud service, it needs license for enable the service to each devices. In “License management”, you can find the status for all devices. The status includes “Available”, “In-use”, “Expiring” as below image.



Here is the introduction of license management.

- Add license: click “+” icon to add the license key.
- Assign license to all device: click “ALL” icon to assign all license you have at the same time.
- Assign license to group: if you already created device group, also can assign the license key for the device group.