


6. Remote Power On/Off (RDM)

Remote Power On/Off

- 1. Launch RDM.
- 2. Use a mouse to navigate to the display you want to control, and then double click the green status indicator.



- 3. A confirmation window will pop up.
- 4. After selecting **Yes**, the status indicator for the display you want to power off will turn orange.

37	Offline	Novo-EE4EA	192.168.96.11		Idle	NovoTouch EK-2 Series	v4.5.1.1113	70:2E:D9:3
----	---------	------------	---------------	--	------	-----------------------	-------------	------------

- 5. If you want to wake a display, double click the orange status indicator.

37	Idle	Novo-EE4EA	192.168.96.11		Idle	NovoTouch EK-2 Series	v4.5.1.1113	70:2E:D9:3
----	------	------------	---------------	--	------	-----------------------	-------------	------------

- 6. The display will wake up.



