

5.1 How to extend your screen? (Windows)

Screen Extension for Windows Computers

Screen extension for Windows computers is a little bit complicated.

- For Windows 10 computers, a Screen Extension driver is required.
- For Windows 7 and 8 computers, no addition driver is needed.

Install Screen Extension Driver for Windows 10

1. Download the Screen Extension driver for Windows 10

Executable version	V1.0.2	3.53 MB	Download
MSI version – please install as admin	V1.0.2	0.74 MB	Download

2. Please note that you will need Admin Privilege to install a driver. Launch the Screen Extension installer and follow the on-screen instructions to complete the process.

Turn On/Off Screen Extension in NovoConnect Software

1. Run NovoConnect Software or LauncherPlus/LauncherOne software and connect to the desired Novo device.
2. When you start projecting your screen, click the

“Screen Extension” icon to toggle between “Duplicate” and “Extend” display modes.

Turn On/Off Screen Extension in NovoConnect Software

1. Run NovoConnect Software or LauncherPlus/LauncherOne software and connect to the desired Novo device.
2. When you start projecting your screen, click the “Screen Extension” icon to toggle between “Duplicate” and “Extend” display modes.

LauncherPlus




Click to duplicate desktop



Click to extend desktop

LauncherOne




Click to duplicate desktop



Click to extend desktop

NovoConnect Software



Click to duplicate desktop



Click to extend desktop

Tutorial Video