


3.11 On-Screen Annotation



Once your PC or laptop screen is mirrored to the NovoTouch, the **On-Screen Annotation** icon is displayed on the bottom-left corner, and is set to a minimized icon by default.




Tap the icon  to expand the tool palette. There are eight features in the feature wheel.

The following table has the description of each tool icon.

Icon	Functions	Description
	Pen & Highlighter	1) Click to enable this tool 2) Long-press to select pen/highlighter, color, & size
	Eraser	Click to enable Eraser

Icon	Functions	Description
	Disable Annotation	Disable on-screen annotation
	Redo	Re-do
	Undo	Un-do

Icon	Functions	Description
	Delete	Delete all on-screen annotation
 Screenshot to all	Snapshot to all participants	Send screen snapshot to all meeting participants (connected users)
 Screenshot to presenters	Snapshot to presenters	Send screen snapshot to presenters

Icon	Functions	Description
	Collapse	Click to collapse the menu palette