



2.6 Change Device Name


1. In the All Apps menu, tap **NT Settings**.




2. In the **NT Settings** menu, tap **General**.



3. Tap **Room Name** to edit the name for the device/display.



4. Once you return to the NT Launcher home screen, you can check for the new device name in the top-right corner.



5. Return to the RVA home screen to see the new device name.

Using Launcher Dongle



Launcher Dongle

No software or network required.
Plug into Windows or Mac PC.

BYOM



Step 1 Toggle BYOM feature

Step 2 Select in room Camera /
Microphone / Speaker /
Speakerphone or Video
Conferencing Software

Using Software

Step 1 Connect to Meeting Room via **NETGEAR**

Step 2 Run "NovoConnect App" to start your presentation

— or —

Open the following website:

<https://launcher.novus.com>

— or —

Use native monitoring on your device



Connection Method

Scan QR Code



Enter IP Address

Novo-EE4EA

192.168.96.11
NETGEAR

BYOM

Go to Menu -> BYOM to enable



v4.5.1.1113 Corporate

