


# How to broadcast Facebook to Novo-series device(s)

Supported models: NovoConnect NC-X700, NC-X900, NovoDisplay, NovoTouch




NovoDS version: NovoDS V4.0.0 and above.



**Step1.** Use DS Studio software or NovoDS.com, create a playlist.

**Step2.** Go to **Social Media widget > Facebook > Facebook Access Id > Get Access ID**




**Step3.** Pop up a Facebook page, please follow Facebook access instruction to get your Facebook Access ID.





**Step4.** Copy and paste your Facebook access ID on the **Facebook Access ID** box.



**Step5.** Once published the playlist you will see your Facebook picture, videos or text content update.



# How to remove your Facebook account from Novo-series Device

Please note that once removed the Facebook Access ID, Facebook will be disconnected with your Novo device(s).

**Step1.** Go back to **get Facebook Access ID** via DS Studio or NovoDS.com then delete your access ID.

Copy your Facebook Access ID and paste to DS Studio or NovoDS.com.

Facebook Access ID

5LBO-ECU2-DRC8-MVMR-WUZQ



Once removed the Facebook Access ID,  
Facebook will be disconnected with your Novo device(s).

CANCEL

REMOVE