

NovoTouch EK4 series User's Manual

EK4 series: EK656i / EK756i / EK866i

1. Get to Know Your Touch Panels

1. [What is NovoTouch EK4 series](#)
2. [Product Features](#)
3. [Companion Software](#)

2. Set Up Your NovoTouch

1. [Installing the Wall Mount](#)
2. [Get Started](#)
3. [Connect your NovoTouch to your network](#)
4. [Setting up a Wi-Fi Hotspot](#)
5. [Turn WiFi off and on](#)
6. [Change device name](#)
7. [Switch input source](#)
8. [Use Remote Manager for installation](#)
9. [Firmware Update with USB Drive](#)

3. NovoTouch Basics

1. [Home Screen](#)
 1. [Change the wallpaper](#)
2. [Launch Pad](#)
3. [Side Bar Tools](#)
4. [NovoConnect](#)
 1. [Using Native Mirroring](#)
5. [NT LiveReceiver](#)
6. [Browser](#)
7. [File Manager](#)
8. [NT AppManager](#)
9. [Whiteboard](#)
10. [Screen Lock](#)
11. [On-Screen Annotation & Touch back](#)
12. [More Apps](#)

4. Advanced Features

1. [NT Settings](#)
2. [Advanced Feature](#)
 1. [Boot-up Time](#)
 2. [Shutdown Time](#)
 3. [Auto Sleep](#)
 4. [Boot Channel](#)
 5. [Wake Up By Input Source](#)
3. [SysControl \(Network-based Control\)](#)
4. [NovoTouch EK-4 RS-232 Control](#)

5. More of NovoConnect Software

1. [Screen Extension](#)
2. [Audio On/Off and Mirroring Mode](#)
3. [Video and YouTube](#)
4. [AirNote](#)
5. [NT LiveNote – On-Screen Annotation & Screen-Share Control](#)
6. [Sharing Files and Webpages](#)
7. [Voting/Polling](#)
8. [Touchback From Projected Screen](#)

6. FAQs and Troubleshooting

1. [How to use remote control to disable touch feature](#)
2. [How to capture log](#)

7. Remote Manager

1. [Introduction](#)
2. [Install Software](#)
3. [Add/Remove Group Device](#)
4. [Add Devices via Auto Discovery](#)
5. [Configure Device Setting](#)
6. [Remote Power On/Off \(RDM\)](#)
7. [Update Firmware](#)
8. [Configure Moderator Credentials](#)
9. [Server mode – Remove Manager DB Server](#)
10. [Use Remote Manager for large deployment](#)

8. Accessories

1. [Mobile Stand VKST41](#)